Preferred Embodiment
Minimal configuration (Single Server)
Fig. 0a



If valid cookie present, skip to step 3...

(0)	Client retrieves disclaimer / registration, etc. page ←	
(1)	Client submits acceptance / registration data, etc. →	
(2)	Server replies with cookie data initialization ←	
(3)	Client retrieves user interface for simulation, calculation, etc. ←	
(4)	Client submits data for calculation: calculation data →	(data saved)
(5)	Server returns "Processing" message w/ emb. refresh + updated cookie data ←	
(6)	Client auto refresh to getresults.pl + new cookie data →	(authenticate & check vs. limits)
(7a)	"Overuse" message ←	if fail
(7b)	Results (Any combo of markup, graphics and data)* ←	if succeed

In drawings 1-4 Client instigates data transfer, arrows indicate direction of transfer

→ Client to Server

← Server to Client

OPTIONAL VALIDATION DATABASE NOT SHOWN
IS TYPICALLY COLOCATED WITH VALIDATION PROCESS,
BUT CAN BE LOCATED ANYWHERE ON AN INTERNET OR INTRANET

Internet Server combined with one or more Private Computation Servers

Fig. 0b



Docket No. 2557.2650

If valid cookie present, skip to step 3...

(0) Client retrieves disclaimer / registration, etc. page

(1) Client submits acceptance / registration data, etc.

(2) Server replies with cookie data initialization

(3) Client retrieves user interface for simulation, calculation, etc.

(4) Client submits data for calculation: calculation data (data saved)

(5) Server returns "Processing" message w/ emb. refresh + updated cookie data

(6) Client auto refresh to getresults.pl + new cookie data (authenticate & check vs. limits)

(7a) "Overuse" message if fail

if succeed → compute

Choose server and send relevant data

Return raw data

(7b) Results (Any combo of markup, graphics and data)* (optional) format raw data

OPTIONAL VALIDATION DATABASE NOT SHOWN
IS TYPICALLY COLOCATED WITH VALIDATION PROCESS.
BUT CAN BE LOCATED ANYWHERE ON AN INTERNET OR INTRANET

Internet Server combined with one or more Client-visible Computation Servers, Method Set C

Fig. 0c



If valid cookie present, skip to step 3...

(0) Client retrieves disclaimer / registration, etc. page

(1) Client submits acceptance / registration data, etc.

(2) Server replies with cookie data initialization

(3) Client retrieves user interface for simulation, calculation, etc.

(4) Client submits data for calculation: calculation data (data saved)

(5) Server returns "Processing" message w/ emb. refresh + updated cookie data

(6) Client auto refresh to getresults.pl + new cookie data (authenticate & check vs. limits)

(7a) "Overuse" message if fail

if succeed → compute

Choose server and send relevant data, forward client to computation server

(7b) Results (Any combo of markup, graphics and data)* and return results

OPTIONAL VALIDATION DATABASE NOT SHOWN
IS TYPICALLY COLOCATED WITH VALIDATION PROCESS,
BUT CAN BE LOCATED ANYWHERE ON AN INTERNET OR INTRANET

Servers 2-n (computation servers)

Internet Server combined with one or more Client-visible Computation Servers, Method Set D

Fig. 0d



If valid cookie present, skip to step 3...

(0) Client retrieves disclaimer / registration, etc. page ←

(1) Client submits acceptance / registration data, etc. →

(2) Server replies with cookie data initialization ←

(3) Client retrieves user interface for simulation, calculation, etc. ←

(4) Client submits data for calculation: calculation data → (data saved)

(5) Server returns "Processing" message w/ emb. refresh + updated cookie data ←

(6) Client auto refresh to getresults.pl + new cookie data →

Choose server and send relevant data, forward client to computation server → (authenticate & check vs. limits)

(7a) "Overuse" message ← if fail

(7b) Results (Any combo of markup, graphics and data)* ← if succeed, compute and return result

OPTIONAL VALIDATION DATABASE NOT SHOWN
IS TYPICALLY COLOCATED WITH VALIDATION PROCESS,
BUT CAN BE LOCATED ANYWHERE ON AN INTERNET OR INTRANET


Disclaimer - Netscape
File Edit View Go Communicator Help
Back Reload Home Search Netscape Print Security Shop
Bookmarks Location: http://24.218.251.135/cgi-bin/Stackup/cgi.pl
Search Projects Members BizJournal SmartUpdate Mktplace Switchboard INTELLICAST AltaVista, Adv
DISCLAIMER AND TERMS OF USE
Accept
Decline
Applet AcceptDecline running

Fig. 1
D5



Docket: CSR-003v2R

Fig. 2A
D6


Netscape: EXPERIMENTAL PCB Cross Section Editor
Forward
Reload
Home
Search
Netscape
Print
Security
Location
http://24.218.253.81/cgi-bin/FieldExtractor2/cgi.pl
What's Related
Configuration
Coupled Microstrips
Units
mils
Setup
Extract
Execute
Upper Left X
Upper Left Y
Width
Height
Name
Copper
Rel. permittivity
Instructions
This evaluation version is limited to just two signal lines: no geometry can be added. Standard configurations are most easily created by selecting a Configuration first, then clicking "Setup" and entering the desired parameters.
A setup can then be customized by modifying the position or size of the signal line with the numeric entry panel at left. After you're satisfied with the new numeric values, press Enter to make the changes permanent. Alternatively, you can click-drag the geometry into approximate position and then use the up or down arrows to nudge into final position.

Fig. 2B
D7


Netscape: EXPERIMENTAL PCB Cross Section Editor
Forward
Reload
Home
Search
Netscape
Print
Security
Location:
http://24.218.253.81/eqn-bin/FieldExtractor2/ce.pl
What's Related
Configuration
Coupled Microstrips
Units
mils
Setup
Extract
Upper Left X
Upper Left Y
Width
Height
Name
Copper
Rel. permittivity
Saving data...
Instructions
This evaluation version is limited to just two signal lines no geometry can be added Standard configurations are most easily created by selecting a Configuration first, then clicking "Setup" and entering the desired parameters
A setup can then be customized by modifying the position or size of the signal line with the numeric entry panel at left After you're satisfied with the new numeric values, press Enter to make the changes permanent Alternatively, you can click-drag the geometry into approximate position and then use the up or down arrows to nudge into final position
You can see how far the selected item is from its adjacent elements by moving the cursor over the adjacent element of interest. If elements overlap, a negative number is shown

Fig. 3
D8

Extracting geometry... - Netscape
File Edit View Go Communicator Help
Back Reload Home Search Netscape Print Security Shop
Bookmarks Location: http://24.218.251.135/Stackup/overuse.html
Search Projects Members BizJournal SmartUpdate Mktplace Switchboard INTELLICAST AltaVista Adv
We're sorry but you've exceeded your extraction quota for today.
Please try again tomorrow.
Document Done

Fig. 4A
D9



Exhibit 2149 p.30

Fig 4B
D10



Express Mail Label No. EV339436626US

Fig 5
D11